


Glastürkühlschrank

M 210

Spare parts list and exploded assembly drawing

Reservedelsliste-Eksploderet

Art. 477800200



Position	Item number	Item name
0009	7511135	Wire for light, required for door reversing from right hinge side to left
0061	0-6538001	Filter drier,
0067	0-5235002	Castor, complete
0087	0-6038175	Base plate fittings, complete
0119	3010842	Defrost water seal
0129	8-036510839	Compressor - Complete EMX3118Y
0144	0-5238226	Holder for evaporator
0153	7535380	Power cord
0154	0-7038254	Cover for multiple plug
0186	0-7038902	Fan, 230V-50/60HZ
0187	7030132	Fan, 230v-50/60Hz.
0199	0-4838236	Key set 2 pcs EUROLOCKS / Kulcs szett (2 kulcs / szett)
0406	0-4050015-19	Evaporator
0705	1510062	Spring
0709	0-52387110103	Bush
0899	0-7211037	Sensor Set
1055	0-52386620103	Covering - black
1202	0-4238408	Grate
1209	6520430	Evaporating tray
2021	0-6238170	WOT condenser
2112	2041842-03	Hinge
2130	0-5239987-19	Wire conduit for top light
2169	0-7220011	Thermostat XR50CX
2170	0-A9301260103	Distance piece
2187	0-7050008	Fan,230v-50/60Hz.
2200	0-028000637	Door, complete, glass
2210	0-5239568-03	Gasket
2410	0-52392990103	Covering, hinge, upperpart
2420	A102530217	"L" Hinge + covering
2421	A102530218	"R" Hinge + covering + tap
2422	3010605-03	Slide shoe, left + right
2423	0-20381290103	Ajustable foot
2430	0-A9151272	Lock complete
2440	0-48381050619	Shelf strip, at the back
2441	0-48381060119	Shelf strip, in front
2451	0-A910316-53	Bracket
2518	0-4012256-03	Bottom panel. skirting board
2524	2042085-19	Covering plate
2600	0-A90135301	Hand lever
2700	2042491	Perforated Steel shelf w. Ø9 holes - FKG883
3106	0-5239612	Light screen
3107	7010203	LED light strip, door
3126	0-7050038	LED light strip
5072	7080120	4-pol plug, 2,5/4-pol
5573	A921321	Electrical parts for compressor
5581	6040558	Heating tube
6554	0-4050019	Top light
6558	7090376	Power Supply
XXXX	1006469	Wire diagram

Subject to changes without prior notice.

Position	Varenummer	Varenavn
0009	7511135	Ledning for lys, påkrævet for dørvendning fra højre hængsel til venstre
0061	0-6538001	Tørfilter,
0067	0-5235002	Hjul - komplet
0087	0-6038175	Fodpladetilbehør, komplet
0119	3010842	Primaflex slange 3/4" (19 mm) grå
0129	8-036510839	Kompressor - komplet - EMX3118Y
0144	0-5238226	Fordamperholder
0153	7535380	Netledning
0154	0-7038254	Dæksel til multistik
0186	0-7038902	Ventilator, 230V-50/60HZ
0187	7030132	Ventilator 230v-50/60Hz.
0199	0-4838236	Nøgle. sæt - 2 stk.
0406	0-4050015-19	Fordamper
0705	1510062	Torsionsfjeder
0709	0-52387110103	Bøsning
0899	0-7211037	Følørsæt
1055	0-52386620103	Afdækning - sort
1202	0-4238408	Gitter
1209	6520430	fordamperskål
2021	0-6238170	WOT condenser
2112	2041842-03	TopHængsel
2130	0-5239987-19	Ledningsfører til toplys 325 mm
2169	0-7220011	Controller XR50CX
2170	0-A9301260103	Afstandsstykke
2187	0-7050008	Ventilator,230v-60Hz
2200	0-028000637	Dør, komplet, glas
2210	0-5239568-03	Gasket
2410	0-52392990103	Afdækning for dørhængsel i sort
2420	A102530217	"L" Hængsel + Afdækning
2421	A102530218	"R" Hængsel + afdækning + tap
2422	3010605-03	Glide sko - højre + venstre
2423	0-20381290103	Stilbare fod
2430	0-A9151272	Lås komplet
2440	0-48381050619	Hyldeskinne, bageste
2441	0-48381060119	Hyldeskinne, forreste
2451	0-A910316-53	Pose med 24 sæt
2518	0-4012256-03	Fodspark
2524	2042085-19	Blæserskærm
2600	0-A90135301	Håndtag
2700	2042491	Stålhylde
3106	0-5239612	Lysafskærmning
3107	7010203	LED lys strip, dør
3126	0-7050038	LED lys strip
5072	7080120	4-pol plug, 2,5/4-pol
5573	A921321	El dele til kompressor
5581	6040558	Heating tube
6554	0-4050019	Toplys
6558	7090376	Power Supply
XXXX	1006469	Wire diagram

Ret til ændringer uden varsel forbeholdes.